

# 1. Installation Instructions

## PREPARATION

The wall where the panel is to be placed should be in good overall condition. Cleaning of the wall is recommended if using the construction adhesive method. Repair any holes prior to panel installation.



## INSTALLATION

### A. Construction Adhesive

Panels can be affixed to the wall using a small bead of construction adhesive on the back of the panel run along the edges as well as in the middle. It is recommended to temporarily affix the panels to the wall with something else (pin nail, screw, bracing) to allow the adhesive to dry. Follow manufacturer instructions for glue use and set up/dry time.



### B. Direct Screw

Panels can be installed on walls and ceilings. For direct application, furring strips installed directly to the wall or ceiling on 600mm centers perpendicular to the panel are recommended. The panel can then be attached to the furring strips by using screws. Location of the screws is at the preference of the end user but is recommended, at the very least, in the corners and center of the panel. Using a colored anodized screw that most closely matches the panel color where the screw is placed, will achieve the best appearance.



### C. Ceiling Installation

In addition to using furring strips (see above), ceiling installations may be achieved by cutting the panel (if not pre cut to desired specification) to fit into a suspended ceiling grid system similar to what is used for typical drop ceilings. Full panel lengths may also be suspended from the ceiling as well. This is best achieved by using threaded eye bolts for attachment and aircraft cable for suspension at the preferred height.

